

Revised Instructions for: Duffel Tote

Read all instructions before beginning project.

Use 1/2" seam allowances unless otherwise noted.

Use longest stitch possible when sewing.

Cutting Instructions:

1. Cut one 14"x 28.25" for bag front
2. Cut two 9" diameter circles for bag sides
3. Cut one 4" x 5" for bag flap
4. Cut two 2" for strap

Assembly Instructions:



Suede Side Sherpa Side

1. Turn in and pin the sherpa side of strap 3/8" onto the suede side along both 48" edges of the strap. Topstitch 1/4" from the raw edge. Repeat for other strap. Fig. 1

2. With suede sides together, pin ends of one strap to the ends of the other. Stitch, making sure not to twist straps. Fig. 2

3. Turn in and pin the sherpa side of tab 1/2" onto the suede side along the two long edges and one short edge of the tab. Topstitch 1/4" from the raw edge. Fig. 3

4. Turn in and pin the sherpa side of bag body 1/2" onto the suede side along the two 14" edges of the bag body. Fig. 4
Topstitch 1/4" from the raw edge.

5. With suede sides facing up, pin the raw edge of tab 1/2" under the bag body at top edge. Topstitch 1/4". Fig. 4

6. With suede sides up, pin straps to bag body 3" in from long sides of bag body. Make sure that strap seams are in the middle of the bag so they will not be seen. Topstitch straps to bag body 1/4" from the edge, starting 3.5" down from top edge. Fig. 5

7. With sherpa sides together, pin one bag side to the bag body. Stitch. Repeat for other bag side. Fig. 6

Cutting Layout

