

Instructions for:

# Reversible Hobo Tote Kit

Read all instructions before beginning project.  
Use 1/2" seam allowance unless otherwise noted.

## Cutting Instructions:

1. Choose the fabric you would like for the outer bag and for the lining.
2. Cut one 27" square from each fabric.
3. Cut four 3"x 10" from lining fabric. These will be the wraps to attach the handles to the bag.
4. Cut one 4" x 10" from outer bag fabric. This will be the flap closure.

## Assembly Instructions:

1. Mark a 4" opening at the center on one side of the lining square. See Fig.1
2. Pin the outer bag square to the lining square with right sides together. Sew around all four sides leaving the 4" opening. Turn the bag right side out, press flat and tuck the raw edge of opening inside 1/2".
3. Fold the flap closure in half with right sides together to measure 4" x 5". Sew along both 5" sides and turn right sides out and press flat. Topstitch around the 3 finished sides. See Fig 2.
4. Tuck raw edge of the flap closure 1" into the opening on the bag square and pin in place. Topstitch 1/4" around the entire square, including the opening. This will be the bag back. See Fig 3.
5. Sew a 2" pleat at the center top edge of the three remaining sides. See fig. 4.
6. Fold the 3"x 10" wraps in half lengthwise, with right sides together and sew down the 10" side. Turn and press flat. Tuck the raw edges in 1/2", topstitch closed.
7. With the lining facing up, pull one of the back corners of the bag square through one ring on the handle to form a 3" loop. See Fig 5. Tie one wrap tightly around the loop 1" below the ring. Wrap the balance of the fabric wrap around the loop and tuck the ends under the wrap. See Fig 6. Repeat this step for the second back corner using the second ring on the same handle.
- 8 Repeat Step 7 with the front two corners and the remaining handle.

